

MOTUL COOLING SYSTEM STOP LEAK

Coolant circuit sealant to stop cooling leakages
Seal additive to add to cooling systems
For all liquid cooled cooling systems

TYPE OF USE

MOTUL COOLING SYSTEM STOP LEAK is designed to be used in all types of Gasoline and Diesel engines, naturally aspirated or turbocharged, with or without catalytic converter, using all kind of fuel.

MOTUL COOLING SYSTEM STOP LEAK effectively seals critical micro cracks and small leaks. Works quickly and easily in all liquid cooled, closed cooling systems.

MOTUL COOLING SYSTEM STOP LEAK is applicable to seal water coolers and heat exchangers, leaking radiator, water pumps, valves, loose connections and cracked coolant hoses without clogging the cooling system.

Recommended for use in passenger cars, commercial vehicles...etc. and industrial heat exchangers.

Can be used in a curative mode or in preventive mode use as well.

Compatible with all types of coolants (inorganic, hybrid, lowbrid & OAT).

Provides a perfect lubrication during sealing process of the coolant circuit.

PERFORMANCES

MOTUL COOLING SYSTEM STOP LEAK, added to engine cooling circuit, allows to:

- Seals critical micro cracks and small leaks without clogging the cooling system
- Improves the performance of valves, thermostats and water pumps
- Decreases engine temperature

RECOMMENDATIONS

Check coolant level.

Add MOTUL COOLING SYSTEM STOP LEAK to warm coolant in the cooling system.

Move all heater controls to "hot" position.

Let the engine idle for approx. 10 minutes.

Check again the coolant level and test if the sealing was successful.

Attention: Open radiator filling cap slowly and successively - system under pressure - risk of burning! 300 ml is sufficient for cooling systems of 12 L capacity.

Do not exceed the recommended proportion.



MOTUL COOLING SYSTEM STOP LEAK

Coolant circuit sealant to stop cooling leakages
Seal additive to add to cooling systems
For all liquid cooled cooling systems

Dangerous. Follow the precautions for use.

SECURITY

Refer to the MSDS sheet and the information mentioned on the product label.

We retain the right to modify the general characteristics of our products in order to offer to our customers the latest technical development.

Product specifications are definitive from the order which is subject to our general conditions of sale and warranty.

MOTUL - 119 Bd Félix Faure - 93303 - Aubervilliers Cedex - BP 94 - FRANCE - Tel: 33 1 48 11 70 00 - Fax: 33 1 48 33 28 79 - www.motul.com



MOTUL COOLING SYSTEM STOP LEAK

Coolant circuit sealant to stop cooling leakages
Seal additive to add to cooling systems
For all liquid cooled cooling systems