



THROTTLE BODY CLEAN

**Throttle body system cleaner
Aerosol**

TYPE OF USE

MOTUL THROTTLE BODY CLEAN is a high-performance cleaner especially developed for cleaning of throttle valve, throttle body, idling control valve, intake valve and the carburetor etc. Cleaning agent for repair, assembly, and regular maintenance work.

PERFORMANCE

Quickly and effectively remove deposits at throttle bodies, throttle valves, idling control valves and intake valves without dismantling.

Regular cleaning improves the idling and engine acceleration performance.

Reduce fuel consumption and exhaust emissions.

Leaves no residues after cleaning.

RECOMMENDATIONS

1. Start engine, let it idle for 5mins and turn it off, dismantle the intake hose from the throttle body.
2. Start the engine again and rev it up to approximately 2500 rpm.
3. Slowly spray MOTUL THROTTLE BODY CLEAN into the throttle valve. Pay attention to control the speed of spraying and the revolving speed of the engine.
4. After spraying, maintain the engine at 2500 rpm for 2-3 min. During the cleaning process, white smoke may be emitted from the exhaust pipe and this is a normal phenomenon.
5. Once product is fully dispensed out, white smoke will not be emitted anymore. After confirming that there is no idling instability, the cleaning operation is completed, and the intake hose can be assembled back.
6. If necessary, dismantle the throttle valve and other components to clean.

SECURITY

Refer to the MSDS and the information mentioned on the product label bottle for further details.

We retain the right to modify the general characteristics of our products in order to offer to our customers the latest technical development.

Product specifications are not definitive from the order which is subject to our general conditions of sale and warranty. – Made in France

MOTUL - 119 Bd Félix Faure - 93303 AUBERVILLIERS CEDEX - BP 94 – Tel : 33 1 48 11 70 00 - Fax : 33 1 48 33 28 79. Web Site: www.motul.fr