

# **MOTUL ENGINE OIL STOP LEAK**

# READY TO USE FLUID

### **DESCRIPTION**

MOTUL ENGINE OIL STOP LEAK is designed to be used in all types of 4 Stroke, Gasoline and Diesel engines, naturally aspirated or turbocharged, with or without catalytic converter, using all kind of fuel. MOTUL ENGINE OIL STOP LEAK effectively seals critical small oil leaks, seepages and leakages. Works quickly and easily in all closed loop oil circuit. Based on a highly effective additive package to stop loss of engine oil caused by leakage. Keeps engine gaskets flexible and stops oil leaking through seals. Compatible with all mineral and synthetic engine oils. Recommended for use in passenger cars, commercial vehicles...etc. and all closed loop oil circuit engines.

## **APPLICATIONS**

MOTUL ENGINE OIL STOP LEAK, added to engine oil circuit, allows to: Seal critical small leaks, seepages and leakages Stop loss of engine oil caused by leakage

# SERVICES AND EQUIPMENT

In addition to its product ranges, MotulTech can provide tools and services for the maintenance and monitoring of your lubricants. Please contact your technical sales representative for more information.

#### Important Notice

All information and rules about health, safety and the environment are mentioned on the safety data sheet. It provides information about risks, safety procedures and first aid emergency rules. It clarifies all procedures to implement in the case of an accidental spillage, and for the disposal of the product and its effects on the environment. The safety data sheet is available on www.motul.com.

Our product contains natural additives which are likely to modify the colour of the concentrates without altering its performance. The specifications of our products are definite only at the time of order, and are subject to our general sale and guarantee conditions. To give our customers the latest technical developments, the general characteristics of our products may vary.