

P3 TYRE REPAIR

**Repairs and reinflates tyres
With or without inner tubes
Spray 300 ml
Aerosol**

TYPE OF USE

All motorcycle tyres with or without inner tubes.

PERFORMANCES

Repairs and reinflates tyres immediately without removal or tools.

Latex based: Does not damage the tyre or the tube.

The MOTUL TYRE REPAIR container is pressurized and permits all types of tyres to be reinflated, for tyres over 15", a second spray might be necessary.

Enables several hundred kilometres to be covered before repairing using the traditional methods.

Shock-resistant aluminium spray.

RECOMMENDATIONS

- Remove if possible the object which caused the puncture.
 - Position the tyre valve at the top.
 - Completely deflate the tyre.
 - Shake vigorously MOTUL TYRE REPAIR.
 - In cold weather, reheat it in your hands or near the engine.
 - Clean the screw on the valve.
 - Screw on the MOTUL TYRE REPAIR connector.
 - Remove the protection capsule.
 - Position the spray upside down.
 - Press the button until the tyre is totally reinflated.
 - Drive immediately for 10 to 20 km at moderate speed so that the product is evenly distributed.
 - Control the pressure as soon as possible and during the following days and adjust it.
- You can confidently drive several hundred kilometres before repairing the tyre in the traditional way.